




# Access Components 1

Access to HDD hard drive and BIOS battery

Written By: Felice Suglia



## INTRODUCTION

Access to HDD hard drive and BIOS battery

---



### TOOLS:


- [Phillips 0 Screwdriver](#) (1)
-

## Step 1 — Battery



- Unlock the latch for fixing the battery to the right.
- Unlock the fixing bolt from the battery to the left.
- Remove the battery pack from the slot.

## Step 2 — Access Components 1



- Using the Philips screwdriver # 0, unscrew the 2 screws from lower cover.
- Check marks indicating the direction in which to remove the cover.
- Remove the bottom cover by pulling it in the direction markers.

## Step 3



- The hard disk HDD and BIOS battery components then appear.

Pour le remontage, suivre les instructions ci-dessus dans l'ordre inverse.

This document was last generated on 2017-06-25 06:47:36 AM.